


Pressure Sensor No. 84375 Series

GENERAL DESCRIPTION

The patented* No. 84375-Series Pressure Sensor contains a weather-proof, snap-acting valve operated by a pressure differential between a Low and High Process pressure. Depending upon model, it vents or blocks a pneumatic signal when the difference between the two measured pressures exceeds an adjustable setpoint. Available in either automatic or manual reset, the sensor has an adjustable setpoint, provision for piped vent operation and is field reversible. (The automatic reset model also has an adjustable differential). Setpoint is virtually unaffected by control pressure change or, in the case of piped-vent, vent back pressure change. In the auto reset model, reset differential can be changed without shifting the setpoint.


For correct operation, control pressure must be provided thru a .81 mm (.032") diameter or smaller orifice.

* Patent 3,986,524



MODELS AVAILABLE

84375-



J.I.C. Symbols

TABLE 1

Suffix	Description	Reset
A	Direct Acting - Vents on Increase	Auto
B	Reverse Acting - Closes Vent on Increase	Auto
C	Direct Acting - Vents on Increase	Manual

TABLE 2

Suffix	Setpoint Range - kPa (In. H ₂ O)
1	2 to 7 (7 to 28)
2	3.5 to 17.5 (14 to 70)

See Page 2 for SPECIFICATIONS

ORDERING INFORMATION

Specify:


1. Model
2. Control Pressure-If not specified, sensor is set using 207 kPa (30 psi).
3. Setpoint-If not specified, set at minimum.
4. Differential (Automatic Reset models only)-If not specified, set at standard.
5. Tagging Information

SPECIFICATIONS

- Valve Housing, Housing Plate and Cover:**Anodized Aluminum Alloy
- Spring Housing:** 316 Stainless Steel
- Springs:** Stainless Steel
- O-Rings:** Fluorocarbon and Neoprene
- Diaphragms and Gasket:** Buna-N on Nylon
- Control Pressure:** 138 to 414 kPa (20 to 60 psi)
- Maximum Control Pressure:** 517 kPa (75 psi)
- Maximum Ambient Temperature:** 71 ° C. (160° F.)
- Repeatability:** ± 1 % of setpoint
- Approximate Shipping Weight:** 1.36 kg (3 lbs.)
- Control Medium:** Air, Natural Gas, Nitrogen, CO2
- Filtration (Minimum):** 25 microns
- Moisture (Pressure Dew Point):**8° C. (15° F.) less than ambient temperature.
- Oil Content (Natural Base):** 5 ppm
- Oil Content (Synthetic Base):** 0 ppm


NOTE: These are suggested minimums for control medium quality. For operation under more adverse conditions, consult factory.

CAUTION: DO NOT EXCEED MAXIMUM TEMPERATURE/PRESSURE RATINGS.



Process and Reset Pressure Characteristics:			
Model No.	Maximum Process Pressure, kPa (Psi)	Standard Reset Differential kPa(In.H2O)	Minimum Process Pressure Drop to Manually Reset, kPa (In. H2O)
84375-A1	172 (25)	.87 (3.5)	
84375-A2	172 (25)	1.5 (6)	
84375-B1	172 (25)	.87 (3.5)	
84375-B2	172 (25)	1.5 (6)	
84375-C1	172 (25)		.37 (1.5)
84375-C2	172 (25)		1.0 (4)

Reset Differential Range: See graph corresponding to instrument model numbers.



INSTALLATION

MOUNTING:

The No. 84375-Series Pressure Sensor may be mounted in any position, although vertical (upright) is recommended. It should be securely mounted on the panel or other suitable surface to prevent excessive vibration using the mounting bracket.

If the measured variable is a liquid, consideration should be given to the liquid level. Since an error in calibration could be caused by the weight of a body of liquid acting on the measuring assembly, it may be necessary to adjust calibration to compensate for the constant weight (See Adjustments).

If the sensor is out of doors or in any way exposed to water, it should be mounted in a position that will prevent water entry into the valve or spring housings. Water trapped in the housing will impair operation and could freeze during winter months. Vent openings should have fittings installed turned down. The 1/8"-27 NPT vent connection can be used for piped vent operation if gas is used.

If the sensor is used with a liquid process pressure, entrapped air in tubing connected to the measuring assembly should be vented. This can be accomplished by bleeding the relief valves at the sensing element.

CONNECTIONS:

The sensor has three 1/8"-27 NPT connections - one for the CONTROL PRESSURE, one for the VENT and one for RELIEF PRESSURE - and two 1/4" - NPT connections - one for the normally LOW PROCESS PRESSURE and one for the normally HIGH PROCESS PRESSURE.

CAUTION: Do not pipe or plug case relief connection. The vent pressure connection from the sensor cannot be used as a supply or control source for any other equipment. Vent backpressure should be held to as low a level as possible.

Control port pressure must be provided through a .8 mm (.032") diameter or smaller orifice using 6 mm (1/4") or 9.5 mm (3/8") O.D. tubing. Using excessive lengths or other than the specified tubing is not recommended.

Tubing and fittings used to connect the sensor must be free of chips, dirt, moisture or other foreign matter.

On fittings, it is recommended that a non-hardening, "anti-seize" type of thread compound be applied to the threads in moderate amount. The first thread should then be wiped clean of excess to avoid compound being deposited inside the relay. Thread sealing tape is not recommended.

DIMENSIONS - Millimeters (Inches)




Figure 1

MAINTENANCE - See Figure 4

WARNING: USE CARE WHEN DISASSEMBLING, SPRING FORCES ARE PRESENT.

Caution: Do not subject O-rings, gasket, or diaphragms to cleaning fluids, acetone, or any halogenated hydrocarbons such as degrease liquids, etc. Clean only with a soft, dry cloth. Metal parts can be cleaned with a suitable solvent, then dried thoroughly before reassembly.

Pressure Assembly

Remove the three screws (detail 37) holding the sensor to its mounting bracket (detail 38). Remove the sensor. Remove the remaining seven screws (detail 40) securing the housing together and (while holding the sensor as shown in Figure 2) remove the lower housing plate (detail 39). Remove the exposed diaphragm and diaphragm shoe together by lifting them out of the upper housing. (Be careful not to lose the short stem protruding from the upper housing). Remove the short stem (detail 34) by simply lifting it out. Remove the four screws (detail 32). The O-ring (detail 28) should come off with the housing. If not, remove it. Replace the defective parts and reassemble* in reverse sequence.

Bushing

To replace the bushing O-ring (detail 26) remove the bushing (detail 25) and replace the defective O-ring. Reassemble* and replace in valve housing (detail 15). Recalibrate if sensor is an automatic reset model.

Spring Housing Assembly

Remove the cap screw (detail 1) and washer (detail 2) and turn the adjustment screw (detail 5) counterclockwise to bring the range spring (detail 6) to its free length. Remove the four screws (detail 11) securing the spring

housing (detail 3) and remove the housing. Remove the range spring and spring seat (detail 4). Reassemble* in reverse sequence.

Valve Housing Assembly

Remove the pressure assembly, spring housing assembly and bushing as described above. Proceed as described under applicable instructions for either the direct-acting or reverse-acting sensor.

Direct-Acting Sensor

Remove the four screws (detail 31) securing the flange that was under the pressure assembly. Remove the flange (detail 30). Prevent the spring seat (detail 9) from rotating and remove the exposed diaphragm clamp. Remove the exposed diaphragm (detail 14). Pull the stem (detail 16) from the valve housing by removing it as an assembly with the remaining flange (detail 13). (The spring seat will remain intact).

Prevent the spring seat from rotating and remove the locking screw (detail 8). Prevent the stem from rotating and remove the spring seat. Remove the flange from the stem assembly. Proceed with the instructions under Direct and Reverse Acting.

Reverse-Acting Sensor

Remove the four screws (detail 31) securing the flange that was under the pressure assembly. Remove the flange (detail 30).

Prevent the spring seat (detail 9) from rotating and remove the locking screw (detail 8). Prevent the exposed diaphragm clamp (detail 10) from rotating and remove the spring seat. Remove the remaining flange (detail 13). Still holding the same diaphragm clamp, remove the newly exposed clamp and diaphragm. Pull the stem (detail 16) from the valve housing with the remaining diaphragm and clamp intact. Proceed with the instructions under Direct and Reverse Acting.

Direct and Reverse Acting Sensors

Remove the remaining diaphragm and clamp. Remove the retaining ring (detail 17) while compressing and holding the spring (detail 19) on the stem. Remove the spring and sleeve (detail 23) to expose the O-ring (detail 20) for replacement. Reassemble* the stem assembly in reverse sequence.

To replace the O-ring (detail 21) in the valve housing, remove the retaining ring (detail 18) and the O-ring directly beneath it. Insert the new O-ring and replace the retaining ring.

To replace the O-ring (detail 22) located in the bellows head, remove the O-ring with a knife or some other sharp pointed instrument. Carefully remove any residue where the O-ring was removed and clean the seating area with a suitable solvent. Dry thoroughly and place a few drops of liquid Viton (Pelmar Laboratories PLV-2000 or equivalent) on the seating area. Clean and place the new O-ring on the seating area. Allow the bond to cure for one or more hours.

With all O-rings, diaphragms, gaskets and defective parts replaced, reassemble* as follows: (refer to Figure 3).

NOTE: For direct-acting hold valve housing as shown in Figure 3; for reverse-acting invert housing.

Be certain that all parts are clean and free of foreign matter. On automatic reset models, turn the differential adjustment screw counterclockwise several turns. Replace the stem, diaphragms and diaphragm clamps.* Hand tighten the clamps and then, while holding each clamp with a wrench, tighten 1/4 turn more.

Replace both flanges and secure with at least two screws (placed diagonally from each other). On the flange where the pressure assembly mounts, replace all four screws* (securing the flange) and snug all screws down.

Replace the spring seat and its locking screw. **DO NOT TIGHTEN YET.** Turn the differential adjustment screw clockwise until it becomes difficult to turn; **DO NOT TIGHTEN.** On manual reset models, depress the reset plunger. Then apply an approximate one-pound force at "P" (see Figure 3) and turn the spring seat to obtain dimension "A." Tighten the locking screw* snug and turn the differential adjustment screw counterclockwise 3/4 turn.

Remove the two screws securing the flange under the spring seat and replace the spring and spring tower assembly. Then replace all four screws* to secure the flange and spring tower.

Reassemble the remainder in reverse sequence and recalibrate.

**NOTE - The following should be fitted using Loctite Sealant "H," or equivalent, applied before reassembly: Spring Seat Screw (detail 8), Diaphragm Clamps, Spring Housing Screws (detail 11), Bushing, Flange Screws (detail 31), Housing Plate Screws (detail 32), Diaphragm Shoe Screw (detail 34) and Cover Screws (detail 37).*

Field Reversal

To change the sensor from direct- to reverse-acting or vice versa, disassemble down to valve housing assembly. Remove the locking screw (detail 8) and spring seat (detail 9). With a long allen wrench, remove the set screw (detail 33) from inside the stem.

Remove the flanges. Invert the valve housing assembly and re-install the set screw all the way to the end of the stem. Replace the flanges and secure with screws. Re-assemble the pressure assembly to the valve housing. DO NOT replace the spring seat or screw at this time. Apply either a 5 psi process pressure to the HP process port or insert a blunt object in the HP process port and push up on the diaphragm shoe with approximately 5 lbs. force. Apply a 30 psi pressure to the control port. Insert the allen wrench at point "P." Apply approximately a one-pound downward force on the allen wrench and slowly turn the set screw clockwise until the sensor vents the control pressure on direct acting models. Then turn one-half turn further. On reverse acting models, first turn the set screw clockwise until the venting stops and then turn counter-clockwise until the sensor vents once more. Then turn one-half turn further. Apply Loctite to set screw.

Complete the re-assembly per previous instructions and recalibrate sensor.

ADJUSTMENTS

SETPOINT

1. Remove cap screw.
2. Apply operating control pressure to inlet port through a .8 mm (.032") diameter or smaller orifice. Control pressure and orifice size must be the same as that used during normal operation.

3. Apply process pressure at desired setpoint to the process port.
4. Insert a 1/8" hex wrench into the adjustment screw and turn screw counter-clockwise (clockwise for reverse-acting units) until the valve snaps open and sensor vents. If the valve is already open, turn the screw clockwise (counter-clockwise for reverse-acting units) until the valve closes, then reverse direction and turn screw until valve snaps open and vents.
5. Check operation and trim as necessary.
6. Replace the cap screw.

DIFFERENTIAL (Applicable to Auto Reset versions only)

CAUTION: Sensor will not vent if differential adjustment screw is turned clockwise to its maximum insertion into the valve housing. Do not set differential below minimum recommended value as shown in graphs.

1. Apply operating control pressure to inlet port through a .8 mm (.032") diameter or smaller orifice. Control pressure and orifice size must be the same as that used during normal operation.
2. Cycle measured pressure at the process port and adjust the differential adjustment screw until desired differential is obtained. Differential is increased by turning the screw counter-clockwise.




Figure 3

TABLE 3

Model No.	Dim. "A," mm (In.)
84375-A, C	1.65 (.065)
84375-B	.51 (.020)

PARTS LIST





Figure 4
84375-A Shown



**MANUAL RESET &
DIFF. ADJ. SCREW**
84375-C

TABULATION

Model No.	Det. 6	Det. 7	Det. 25
84375-A1	33980-H1	33970-B67	33964-A2
84375-A2	33980-G1	33970-B68	33964-A2
84375-B1	33980-H1	33970-B69	33964-A2
84375-B2	33980-G1	33970-B70	33964-A2
84375-C1	33980-H1	33970-B71	33964-B2
84375-C2	33980-G1	33970-B72	33964-B2

Det. No.	No. Req'd	DESCRIPTION	Prod' Part No.
1	1	Cap Screw	33718-G0509
2	1	Washer	24425-A1
3	1	Spring Housing	84366-A1
4	1	Spring Seat	24557-B1
5	1	Adjustment Screw	24558-A2
6	1	Range Spring	See Tab.
7	1	Name Plate	See Tab.
8	1	Screw	33713-G1109
9	1	Spring Seat	33968-A2
10	2	Diaphragm Clamp	33969-A1
11	4	Screw	33713-G1309
*12	1	Gasket	33971-A1
13	1	Flange	33966-B1
*14	2	Diaphragm	33972-A1
15	1	Valve Housing	84364-A1
16	1	Stem	33973-B1
*17	1	Retaining Ring	36605-Q9
*18	1	Retaining Ring -Incl. in Det. 15	36605-B2
19	1	Spring	33975-A1
*20	1	"O"-Ring	36240-V0010
*21	1	"O"-Ring - included in Det. 15	36240-V0016
*22	1	Quad Ring - included in Det. 15	36243-V0012
23	1	Sleeve	33974-A2
24	1	Reset Plunger	33962-A2
25	1	Bushing	See Tab.
*26	1	"O"-Ring	36240-V0007
27	1	Differential Adjustment Screw	33963-A1
†*28	1	"O"-Ring	36240-C0030
29	1	Spring	33965-A1
30	1	Flange	33966-B2
31	4	Screw	33713-K1309
32	4	Screw	33997-A1
33	1	Set Screw	33995-A1
34	1	Stem	33996-A1
35	1	Housing Plate	83898-C1
36	1	Diaphragm Assembly	83899-A1
37	3	Screw	33713-G1309
38	1	Bracket	33603-C1
39	1	Housing	83897-C1
40	7	Screw	33713-G1109
41	10	Nut	36603-A22
†42	1	Diaphragm - not shown	30873-A2
†43	2	Air Check Valve - not shown	26179-C1
†44	1	Quad Ring - not shown	36243-N0006
†45	1	Retaining Ring - not shown	36605-C1

NOTE: For complete kit containing all "O"-rings, gaskets, diaphragms and retaining rings to service one valve body, order Repair Kit No. 82665-G1. This kit contains details marked *.

For complete kit containing all "O"-rings, retaining ring, and diaphragm to service one pressure assembly, order Repair Kit No. 82665-N1. This kit contains details marked †.

Robertshaw

U.S.A. and CANADA

Robertshaw Industrial Products Division
1602 Mustang Drive
Maryville, Tennessee 37801
Phone: (865) 981-3100 Fax: (865) 981-3168
<http://www.robertshawindustrial.com>

Exports

Invensys Appliance Controls
1701 Byrd Avenue
P.O. Box 26544
Richmond, Virginia 23261-6544
Phone: (804) 756-6500 Fax: (804) 756-6561