
Measuring wheels

Application


In order to avoid errors when using measuring wheel actuation, it is important that the slip is kept as low as possible. When choosing a profile (surface structure), special attention must be given to the properties the material being measured, such as elasticity, thickness and interaction resistance. Slippage is also influenced by the width of the contacting

measuring wheel, the pressure of contact, the tensile stress in the material that is being measured and the angle of wrap. The angle of wrap should be as large as possible. Wheel bodies are made of cast metal or plastics (see designation). The position of the measuring wheel should be chosen such that the material moves away from the bearing of the sensor.

Correct Measuring wheel or pulse generator



Wrong
Measuring wheel or pulse generator




Measuring wheel circumference/ transmission ratio

Use the following measuring wheels for different transmission ratios of counters:


Counter transmission	measuring wheel			
ratio	circumference			
500:1	0.2 m (1/5 yd.)			
50:1	0.2 m (1/5 yd.)			
5:1	0.2 m (1/5 yd.)			
2:1	0.5 m (1/2 yd.)			
1:2	0.2 m (1/5 yd.)			
1:5	0.5 m (1/2 yd.)			
1:20	0.2 m (1/5 yd.)			
1:50	0.5 m (1/2 yd.)			

Measuring wheels

Overview




1 with rims, aluminium with fine cross knurling Used e.g. for threads and yarns




2 Rubber profile, glued on Used e.g. for paper and cardboard, cable measurement, non-greasy metal, fleece, wood (rough or finished), soft and hard plastic materials;

A = soft, highly adhesive rubber coating B = good-grip, low-wear rubber



3 Rubber coating with parallel knurling, vulcanized
Used e.G for rubber, leather. textiles, floorings, glass

4 Aluminium with parallel knurling Used e.g. for rubber, soft plastic materials, wood with rough surface, certain textiles




5 With rims, aluminium with parallel knurling Used e.g. for threads, yarns, ribbons


Measuring wheel circumference/ transmission ratio


The following measuring wheels are to be used for the different transmission ratios:

Transmission ratio	Meassuring whee
	circumference
500:1	0,2 m (1/5 yd.)
50:1	0,2 m (1/5 yd.)
5:1	0,2 m (1/5 yd.)
2:1	0,5 m (1/2 yd.)
1:2	0,2 m (1/5 yd.)
1:5	0,5 m (1/2 yd.)
1:20	0,2 m (1/5 yd.)
1:50	0,5 m (1/2 yd.)

Measuring wheels







7 Card band Used e.g. for carpets and coarse textiles

Order information

		Width of		Bore Ø		
Circumf.	Profile	contact surf.				
		mm	4.0 mm	6.0 mm	7.0 mm	10.0 mm
0.2 m	1	4	0 601 014	0 601 015	0 601 017	
	2 A	12	0 601 018			
	2 B	12	0 601 118	0 601 048		0 601 049
	2 A	24	0 601 020		0 601 092	
	2 B	24			0 601 192	
	4	20.5	0 601 023			
	4	20	#		0 601 093	<u> 12</u>
	5	16.5	0 601 026		0 601 094	
0.5 m	2 A	25			0 601 050	
	2 B				0 601 150	0 601 151
	3	25			0 601 059	0 601 156
	4	25			0 601 051 2	0 601 157
	5	16			0 601 052	
	6	25			0 601 063	0 601 163
	7	26.5			0 601 054	(1)
1/5 yd.	1	4	0 601 034	44 44 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4	0 601 037	
	2 A	24	0 601 042		0 601 095	
	5	16.5			0 601 096	
1/2 yd.	2 A	25	42		0 601 060	
	4	25			0 601 061	
Fuß	2 A	25			U 60 1 07 .T	
	2 B	25			0 601 171	
	4	25			0 601 070	

¹ Same version, but plastic,

ordering code 0 601 121

ordering code 0 601 300

Inquire for other measuring wheels
Ordering codes printed in bold have priority delivery handling.

² Same version, but plastic, Same version, but with PTB approval,

³ Same version, but plastic,

ordering code 0 601 100 ordering code 0 601 301