INTRODUCTION

The instruction manual is the proper document to be used for the installation, setup and calibration of the Model 7000 Excalibur. However, due to the instruction manual's size and the number of options, it gives the appearance of being very complicated and tends to be intimidating. Therefore, this document was created to provide a simplified illustration of various setup and calibration procedures based upon the type of measurement desired. Only illustrations of the more common types of measurements are shown here, however, they may still be of some help. This document is not intended to replace the instruction manual and is not applicable unless the control unit, PFM Transmitter and probe have been properly installed.

If the instrument is to be used as a PID Controller, first perform the setup & calibration with the PID Control off as specified in this guide. Then refer to the setup & calibration guide for the PID Controller.

The key to understanding the Model 7000 is knowing how to navigate through the menu. The following describes the various displays and keys used for setup and calibration:

DISPLAYS



VFD Line 1 – indicates the mode to be setup or calibrated. VFD Line 2 – indicates the sub-mode and/or value being entered.

KEYS

SETUP	To put the instrument into the setup mode.
CALIBRATE	To put the instrument into the calibrate mode.
ENTER	To put the instrument into a sub-mode and to store data.
	To scroll up through the menu.
LAST	To scroll down through the menu.
NUMERIC	To enter data.
CLEAR	To return to the previous mode (to back out of a mode). Also used to erase a keypad entry before pressing the ENTER key.

HELPFUL HINTS

*Scrolling, as indicated by either \triangle or ∇ can be done in either direction regardless of the direction shown. *After energizing the instrument, but before starting the setup and calibration procedure, check to make sure that the LED in the PFM Transmitter is pulsing.

*If attempts were made to setup and calibrate the instruments and it is desirable to return to the default condition, perform the initialization procedure (Initialize database).

*Do not be concerned with the error light before setup and calibration is complete.

ENTRY	REMARKS
SETUP —	Access Level appears in VFD line 2.
ENTER	Limited appears in VFD line 2.
	Scroll until Full appears in VFD line 2.
ENTER	ー Password? Appears in VFD. ★★★★★★+->
NUMERIC	Enter password using appropriate keys. 12345 is default password
ENTER	Full appears in VFD line 2.
CLEAR	— Access Level appears in VFD line 2.
	 Scroll until Diagnostics appears in VFD line 2.
ENTER	PFM Input Test appears in VFD line 2.
	— Scroll until Initialize Database appears in VFD line 2.
ENTER	— All Except PFM Input appears in VFD line 2.
LAST \bigtriangledown	Scroll until Full Initialization appears in VFD line 2.
ENTER	Initialize Database appears in VFD line 2 after a short wait.
CLEAR	Diagnostics appears in VFD line 2.
CLEAR -	VFD line 2 is blank.

INITIALIZE DATABASE

Initialization complete.

KEYPAD

SETUP AND CALIBRATION



Determine the Maximum Level. This is the highest point that can possibly be measured. This is usually, but not always, the same as the tank height. Fill in the value below.

The Upper Range Value for Level should be the same as the Maximum Level. For the Lower Range Value for Level use 0. Fill in the values below.

Determine the Lower Range Value for Volume. This point is usually on the active portion of the probe as it is normally the lowest point that can be measured. (No indication of level or volume change can occur when the process drops below the end of the probe.) This is the point at which the ERROR LED will light on decreasing level and, when the instrument has an analog output, it is the point at which the output is 4 ma. Fill in the value below.

Determine the Upper Range Value for Volume. When the instrument has an analog output it is the point at which the output is 20 ma. If the instrument does not have an analog output the Upper Range Value should be the Volume at the Maximum Level. Fill in the values below.

Tank Height:	Maximum Level:	
Tank Radius:	Lower Range Value - Level: <u>0</u>	Lower Range Value – Volume:
Cone Height:	Upper Range Value - Level:	Upper Range Value – Volume:

KEYPAD ENTRY	REMARKS
SETUP —	Access Level appears in VFD line 2.
ENTER	Limited appears in VFD line 2.
	Scroll until Full appears in VFD line 2.
ENTER	Password? appears in VFD line 2.
NUMERIC	Enter password using appropriate keys. 12345 is default password.
ENTER	Full appears in VFD line 2.
CLEAR	— Access Level appears in VFD line 2.
	Scroll until Measurement Mode appears in VFD line 2.
ENTER	Level Only appears in VFD line 2.
	Scroll until Level & Volume appears in VFD line 2.
ENTER	— Measurement Mode appears in VFD line 2.
	Scroll until PID Mode appears in VFD line 2.
ENTER	Off appears in VFD line 2.
ENTER	 Setup Menu appears in VFD line 1. PID Mode appears in VFD line 2.
See note-►	If VFD does not look like the above press CLEAR .
	— Scroll until PV Display Variable appears in VFD line 2.
ENTER	Level appears in VFD line 2.
	Scroll until Volume appears in VFD line 2.
ENTER	PV Display Variable appears in VFD line 2.
	 Scroll until SP Display Variable appears in VFD line 2.
ENTER	Level appears in VFD line 2.
ENTER	— SP Display Variable appears in VFD line 2.
	Scroll until VFD Line 1 Variable appears in VFD line 2.
ENTER	Output % appears in VFD line 2.
ENTER	- VFD Line 1 Variable appears in VFD line 2.

KEYPAD ENTRY	REMARKS
№ХТ∕	Scroll until VFD Line 2 Variable appears in VFD line 2.
ENTER	— Output % appears in VFD line 2.
	Scroll until PFM Input Counts appears in VFD line 2.
ENTER	— VFD Line 2 Variable appears in VFD line 2.
CLEAR —	XX.XX percent appears in VFD line 1 XXXXX usec appears in VFD line 2.

Setup is complete.



KEYPAD ENTRY	REMARKS				
NEXT	Scroll until Damping Time Appears in VFD line 2.				
ENTER	Level Damping Time appears in VFD. X.X->				
NUMERIC	Enter 0. If a damping time is desired, it is recommended that it be added after the system is in operation.				
ENTER	Damping Time appears in VFD line 2.				
CLEAR	— Level appears in VFD line 2.				
	Scroll until Volume appears in VFD line 2.				
ENTER	— Units appears in VFD line 2.				
ENTER	— gallons appears in VFD line 2.				
$\nabla \triangle$	Scroll until desired units appears in VFD line 2.				
ENTER	— Units appears in VFD line 2.				
	— Scroll until Vessel Type appears in VFD line 2.				
ENTER	— Vertical Cylinder appears in VFD line 2.				
	— Scroll until Vert w/Cone Bottom appears in VFD line 2.				
ENTER	 Tank Dimensions appears in VFD. Tank Height 				
ENTER	— XXX.XX-> appears in VFD line 2.				
NUMERIC	Enter Tank Height using appropriate keys.				
ENTER	Tank Height appears in VFD line 2.				
	— Scroll until Tank Radius appears in VFD line 2.				
ENTER	— XX.X-> appears in VFD line 2.				
NUMERIC	Enter Tank Radius using the appropriate keys.				
ENTER	— Tank Radius appears in VFD line 2.				
	— Scroll until Cone Height appears in VFD line 2.				
ENTER	X.X-> appears in VFD line 2.				
NUMERIC	Enter Cone Height using appropriate keys.				

KEYPAD ENTRY	REMARKS
ENTER	Cone Height appears in VFD line 2.
CLEAR	Vert w/Cone Bottom appears in VFD line 2.
CLEAR	— Vessel Type appears in VFD line 2.
	— Scroll until Upper Range Value appears in VFD line 2.
ENTER	— Upper Range Value appears in VFD. XXX.XX->
NUMERIC	Enter Upper Range Value (Volume) using the appropriate keys.
ENTER	Upper Range Value appears in VFD line 2.
	— Scroll until Lower Range Value appears in VFD line 2.
ENTER	 Lower Range Value appears in VFD. X.XX->
NUMERIC	Enter Lower Range Value (Volume) using the appropriate keys.
ENTER	Lower Range Value appears in VFD line 2.
CLEAR	— Volume appears in VFD line 2.
$\nabla \bigtriangleup$	— Scroll until Input appears in VFD line 2.
ENTER	Two Point appears in VFD line 2.
ENTER	— Lo Level Input Cal appears in VFD. X.XX->
NUMERIC	 With the process in the vessel at any known level, preferably low, enter that level using the appropriate keys.
ENTER	— Hi Level Input Cal appears in VFD. XX.XX->
NUMERIC	With the process in the vessel raised to a higher level (preferably quite higher), enter that level using the appropriate keys.
ENTER	Two Point appears in VFD line 2.
CLEAR	— Input appears in VFD line 2.
	XX.XX percent appears in VFD line 1. XXXXX usec appears in VFD line 2.

Calibration is complete. Proceed to the Setting The Alarms.

SETTING THE ALARMS

There are 4 process alarms which may be used to indicate an alarm condition at a predetermined level or volume. There are also 2 output alarms which may be used to indicate an alarm condition at a predetermined % of the 4-20 ma output span or, if no 4-20 ma output, % of span between the Lower Range Value and the Upper Range Value.

Any, or all of the alarms may be enabled. For disabled alarms use the instructions below. For enabled alarms skip this page and proceed to the next applicable page.

DISABLED ALARMS

KEYPAD ENTRY	REMARKS
CALIBRATE	Level appears in VFD line 2.
$\bigtriangleup \nabla$	 Scroll until Alarms appears in VFD line 2.
ENTER	— Process Alarm #1 appears in VFD line 2.
$\bigtriangleup \nabla$	— Scroll until desired Alarm appears in VFD line 2.
ENTER	— Status appears in VFD line 2.
ENTER	Disable appears in VFD line 2.
ENTER	Status appears in VFD line 2.
CLEAR	— Xxxxxxx Alarm #X appears in VFD line 2.
$\bigtriangleup \nabla$	If additional alarms are to be disabled, scroll until the next desired Alarm appears in VFD line 2 and repeat the above. After all desired alarms have been disabled, proceed as follows.
CLEAR	— Alarms appears in VFD line 2.
CLEAR —	XX.XX percent appears in VFD line 1. XXXXX usec appears in VFD line 2.

ENABLED ALARMS

Before proceeding, determine at which point each enabled alarm is to be set, whether it is to be LLFS (Low Level Failsafe) or HLFS (High level Fail Safe), and if it is to have a differential. Fill in the information below as this will be required when setting up the alarms.

	ALARM #1	ALARM #2	ALARM #3	ALARM #4
STATUS Enable or Disable				
MEASUREMENT Level or Volume				
FAILSAFE MODE				
ALARM TYPE FXD or ADJ Differential				
LOW SETPOINT See Note 1 below				
HIGH SETPOINT See Note 2 below				
OFF DELAY				
ON DELAY				
OUTPUT RELAY None, #1, #2, #3 or #4				

PROCESS ALARM SETTINGS

OUTPUT ALARM SETTINGS

	ALARM #1	ALARM #2
STATUS Enable or Disable		
FAILSAFE MODE		
ALARM TYPE FXD or ADJ Differential		
LOW SETPOINT See Note 1 below		
HIGH SETPOINT See Note 2 below		
OUTPUT RELAY None, #1, #2, #3 or #4		

NOTES:

1. LOW SETPOINT is applicable only if the alarm FAILSAFE MODE is LLFS or if the ALARM TYPE is ADJ.

2. HIGH SETPOINT is applicable only if the alarm FAILSAFE MODE is HLFS or if the ALARM TYPE is ADJ.

ENABLED PROCESS ALARMS

KEYPAD ENTRY

R	EN	ſΔ	R	KS



KEYPAD ENTRY	REMARKS
NUMERIC	Enter High Setpoint using appropriate keys.
ENTER	- High Setpoint appears in VFD line 2.
	— Scroll until Off Delay appears in VFD line 2.
ENTER	— X.X-> appears in VFD line 2.
NUMERIC	Enter 0 or desired Off Delay time.
ENTER	— Off Delay appears in VFD line 2.
	— Scroll until On Delay appears in VFD line 2.
ENTER	— X.X-> appears in VFD line 2.
NUMERIC	Enter 0 or desired On Delay time.
ENTER	— On Delay appears in VFD line 2.
	— Scroll until Output Relay appears in VFD line 2.
ENTER	— NONE appears in VFD line 2.
$\bigtriangleup \bigtriangledown$	Scroll until desired Relay or None appears in VFD line 2.
ENTER	Output Relay appears in VFD line 2.
CLEAR	— Process Alarm #X appears in VFD line 2.
$\bigtriangleup \nabla$	If additional Process Alarms are to be enabled, scroll until the next desired process Alarm appears in VFD line 2 and repeat the above. After all desired Process Alarms have been enabled, proceed as follows:
CLEAR	— Alarms appears in VFD line 2.
CLEAR -	XX.XX percent appears in VFD line 1. XXXXX usec appears in VFD line 2.

If any Output Alarm is to be enabled, proceed to next page. If not, Calibration is complete.

ENABLED OUTPUT ALARMS

KEYPAD ENTRY

D	FN	ЛА	D	CC.
	1.1	'LA	LIN.	NO.





Calibration is complete.