

GENERAL DESCRIPTION

The Model CR-101 Series A and B Ratio Relays are proportioning units designed for use in industrial pneumatic control systems where the application requires amplifying or reducing the volume of control air to the final control devices. The relay components are made of steel and aluminum and the diaphragms are Buna-N on nylon.

SPECIFICATIONS

DESIGN DATA Input-Output Ratios:

Amplifying	Reducing		
	1.2:1		
1:1.5	1.5:1		
1:2	2:1		
1:3	3:1		
1:4	4:1		
1:5	5:1		
1:6	6:1		

SPECIFICATIONS

DESIGN DATA

Input Pressure Range (P1):

25 psig (1.8 bar) maximum for amplifying 90 psig (6.3 bar) maximum for reducing

Supply Pressure:

60 psig (4.2 bar)	maximum (should be at least 10
psig [0.7 bar] grea	ter than output pressure)
Output Pressure:	50 psig (3.5 bar) maximum
Action	Proportional

	I Toportional
Ambient Temperature Limit	ts:40 to 180° F. (-40 to 82°)
Biasing Adjustment (Fs):	$\pm 18 \text{ psig} (1.2 \text{ bar})$
Connections:	
(Exhaust cor	nection is 1/16" female NPT.)
Weight:	1.2 lbs. (0.54 Kg)

PERFORMANCE DATA

Ultimate Sensitivity:......0.1% of full range Supply Pressure Effect:Change in output pressure for a 5 psig (0.35 bar) supply pressure change: Less than 1% of full range. Ambient Temperature Effect: ..Change in output for a 75 F (24° C) change in ambient temperature: 0.5% of full range. Sales Manual Section 332 PRODUCT SPECIFICATION CR-101-A/B

Ratio Relay Adjustable Bias CR-101-Series A & B



Air Consumption: Maximum	3.0 SCFH
For Maximum Flow:	
Supply output capacity	
	5.0 SCFM nominal


ORDERING INFORMATION

Specify ratio of input to output.

Amplifying Relays		Reducing Relays	
Model No.	Ratio	Model No.	Ratio
		81032-K2	1.2:1
81032-G6	1:1.5	81032-K1	1.5:1
CR101-A2	1:2	CR101-B2	2:1
CR101-A3	1:3	CR101-B3	3:1
CR101-A4	1:4	CR101-B4	4:1
CR101-A5	1:5	CR101-B5	5:1
CR101-A6	1:6	CR101-B6	6:1

DIMENSIONS

This relay will operate properly when mounted in any position.



OPERATION


The output pressure is proportional to the input pressure as the effective area of the input diaphragm is to the effective area of the output diaphragm when the biasing spring is adjusted to zero load. The relay is in a balanced position when the input pressure, plus the effect of the biasing spring, is balanced by the output pressure and both surfaces of the valve are seated. The illustration (Figure 2) shows a 1:6 amplifying relay.

When the input pressure is applied to the relay, air enters the input chamber and acts on the input diaphragm. As the input pressure increases, this pressure acts to move the center assembly downward, closing the exhaust portion of the valve and opening the lower portion of the valve. This permits supply air to enter the output chamber. This air pressure acts on the output diaphragm and also passes out of the output port.

Since the effective area of the input diaphragm, in this case, is six times as large as the effective area of the output diaphragm, the output pressure will have to be six times as great as the input pressure, and it will also have to balance the effect of the biasing spring in order to balance the unit. As the increasing output pressure approaches the balance point, the center assembly will begin to rise, permitting the valve to close, thereby throttling the flow of the supply air.

A further increase in the input pressure will cause the lower portion of the valve to open until the unit is again in balance. A decrease in the input pressure will permit the output pressure to raise the center assembly until the exhaust valve seat clears the upper surface of the valve, exhausting pressure until the unit is again in balance.

Turning the adjusting screw clockwise or counterclockwise, respectively, provides advanced or retarded biasing of the output pressure.





U.S.A. and CANADA Robertshaw Industrial Products Division 1602 Mustang Drive Maryville, Tennessee 37801 Phone: (865) 981-3100 Fax: (865) 981-3168 http://www.robertshawindustrial.com

Exports

Invensys Appliance Controls 1701 Byrd Avenue P.O. Box 26544 Richmond, Virginia 23261-6544 Phone: (804) 756-6500 Fax: (804) 756-6561

invensys.

Q-3576 (5/04)